

## Installation instructions for Uridan water-free urinal model GVF-1

### Important notes:

- The urinal **must** be installed in accordance with the AS/NZS 3500 Plumbing Requirements
- Ensure that existing sewer pipes are well cleaned and don't have pre-existing blockages
- This Uridan urinal is already trapped. **DO NOT** connect to another p-trap
- Ensure that noggings and studs are positioned at the appropriate height to allow for fastening of mounting bracket
- Please leave customer care booklet, Uriclean cleaning detergent and hook with customer

### Installation process

- Drill the holes for top mounting bracket 838mm from floor.
- Attach bracket to wall ensuring that the top edge of the bracket bends **toward** the wall.
- Rough-in 50mm PVC DWV waste at 107mm from finished wall rising up 415mm high.
- Attach 50mm socket (F&F) to end of waste pipe
- Glue PVC adapter (supplied) into socket and grease rubber seal.
- Position support lower support plate bracket and secure to wall.
- Slide the urinal down over top bracket ensuring the bottom of the waste trap is secure in the waste outlet and lower shroud slips behind bottom plate
- Apply silicone sealant around outer edge of urinal and wall if required.

### Preparing the urinal for use

- Pour approximately 1 litre of water in the trap, until level with the top of small waste pipe.
- Insert the stainless steel waste cover and then pour 1 bottle of **URILOCK** fluid over the cover.
- Allow to drain and then spray bowl with Uriclean and wipe.

