

Installation instructions for Uridan water-free urinal model GVT-2

Important notes:

- The urinal **must** be installed in accordance with the AS/NZS 3500 Plumbing Requirements
- Ensure that existing sewer pipes are well cleaned and don't have pre-existing blockages
- This Uridan urinal is already trapped. **DO NOT** connect to another p-trap
- Ensure that noggings and studs are positioned at the appropriate height to allow for fastening of mounting bracket
- Please leave customer care booklet, Uriclean cleaning detergent and hook with customer

Installation process

- The urinal attached to a vertical 50mm PVC waste pipe
- Position the urinal over the waste outlet and mark the 4 holes around base of urinal
- Drill and plug 4 holes
- Using 2 x 45 degree bends attach the sewer pipe to the bottom of the waterlock
- Insert PVC adapter (included with installation kit) into the end of the PVC waste pipe
- Reposition the urinal over the waste pipe and slide in position
- Secure urinal to floor with 4 bolts
- Position the urinal Apply silicone sealant around outer edge of urinal and floor if required.

Preparing the urinal for use

- Pour approximately 1 litre of water in the trap, until level with the top of small waste pipe.
- Insert the stainless steel waste cover and then pour 1 bottle of **URILOCK** fluid over the cover.
- Allow to drain and then spray bowl with Uriclean and wipe.

