

## Installation instructions for Uridan water-free urinal model KHC-2

### Important notes:

- The urinal **must** be installed in accordance with the AS/NZS 3500 Plumbing Requirements
- Ensure that existing sewer pipes are well cleaned and don't have pre-existing blockages
- This Uridan urinal is already trapped. **DO NOT** connect to another p-trap
- Ensure that noggings and studs are positioned at the appropriate height to allow for fastening of mounting bracket
- Please leave customer care booklet, Uriclean cleaning detergent and hook with customer

### Installation process

- Drill 2 pilot holes for mounting bolts 740mm from floor and 215mm apart.
- Screw in 2 mounting bolts until plastic sheathing touches wall.
- Rough-in 50mm PVC DWV waste at 350mm from finished floor.
- Attach 50mm 88 degree bend (F&F) and glue in at 100mm centre from wall.
- Glue PVC adapter (supplied) into end of bend and grease rubber seal.
- Position support lower support bracket under bend and secure to wall.
- Slide the urinal down over 2 mounting bolts ensuring the bottom of the waste trap is secure in the waste outlet.
- Apply silicone sealant around outer edge of urinal and wall if required.

### Preparing the urinal for use

- Pour approximately 2 litres of water in the trap, until level with the top of small waste pipe.
- Insert the stainless steel waste cover and then pour 1 bottle of **URILOCK** fluid over the cover
- Allow to drain and then spray bowl with Uriclean and wipe.

